

ClearReader+ - Les différentes voix :

	LANGUAGE	VOICE	GENDER		LANGUAGE	VOICE	GEN.
1	English (U.S.)	Jill	F(female)	22	Spanish (Castilian)	Diego	M
2	English (U.S.)	Samantha	F	23	Spanish (Castilian)	Monica	F
3	English (U.S.)	Tom	M(male)	24	Catalan	Nuria	F
4	English (British)	Daniel	M	25	Czech	Zuzana	F
5	English (British)	Serena	F	26	Danish	Ida	F
6	English (Australian)	Karen	F	27	Finnish	Mikko	M
7	English (Australian)	Lee	M	28	Greek	Alexandros	M
8	English (Indian)	Sangeeta	F	29	Hungarian	Eszter	F
9	English (South African)	Tessa	F	30	Italian	Paolo	M
10	German	Anna	F	31	Italian	Silvia	F
11	German	Steffi	F	32	Norwegian	Stine	F
12	German	Yannick	M	33	Polish	Agata	F
13	French	Thomas	M	34	Portuguese	Joana	F
14	French	Virginie	F	35	Portuguese (Brazilian)	Raquel	F
15	French (Canadian)	Felix	M	36	Romanian	Simona	F
16	French (Canadian)	Julie	F	37	Russian	Milena	F
17	Dutch (Belgian)	Ellen	F	38	Slovak	Laura	F
18	Dutch	Claire	F	39	Swedish	Alva	F
19	Dutch	Xander	M	40	Swedish	Oskar	M
20	Spanish (Mexican)	Javier	M	41	Turkish	Aylin	F
21	Spanish (Mexican)	Paulina	F	42	English (Irish)	Moira	F

Pour naviguer entre les 4 voix préinstallées:

Il faut rester appuyer sur le bouton avance et tourner le bouton de la vitesse de lecture.

Pour modifier les 4 voix :

Il faut rester appuyer sur le bouton avance et arriere et appuyer sur le bouton lecture/pause : la machine annonce les instructions du menu voix.

Parcourir les 42 voix disponibles par le bouton avance et activer les 4 voix souhaitées en appuyant sur lecture/pause.

Une fois les 4 voix activées, appuyer sur le bouton scan pour valider votre choix.

Pour ne pas faire de changement et sortir du menu voix : presser le bouton arriere.

Pour verifier le choix des voix : Il faut rester appuyer sur le bouton avance et tourner le bouton de la vitesse de lecture.